

## ENVIROMUX-SEMS-16 BATTERY REMOVAL AND DISPOSAL INSTRUCTIONS

The NTI ENVIROMUX-SEMS-16 Server Environment Monitoring System contains a sealed lead acid battery that must be removed from the unit and properly disposed of at the end of the life of the ENVIROMUX-SEMS-16.

**For battery replacement**, do not use these instructions. Battery replacement must be performed by an authorized trained technician only. Please contact Network Technologies Inc at **(800) 742-8324** (800-RGB-TECH) or **(330) 562-7070** to receive a return goods authorization. All packaging and shipping expenses will be the sole responsibility of the customer.

To remove the battery for disposal, carefully follow all instructions.




**RISK OF ELECTRIC SHOCK! FAILURE TO FOLLOW ALL INSTRUCTIONS MAY RESULT IN ELECTRICAL SHOCK.**

**Disconnect ALL power and connection cables from the ENVIROMUX before proceeding.**

1. Remove 10 Phillips-head screws securing the cover of the ENVIROMUX to expose the components inside.
2. Locate the battery inside the ENVIROMUX. (See figure below)
3. Remove the two wires connected to the battery using pliers.
4. Remove the 4 Phillips-head screws securing the two brackets holding the battery to the case. Screw heads are accessible from the bottom side of the ENVIROMUX.
5. Remove and dispose of the battery according to local requirements.

For instruction on the proper disposal of the battery, either contact the Rechargeable Battery Recycling Corporation (RBRC) at 800-822-8837 or go to their website at [www.call2recycle.org](http://www.call2recycle.org). Disposal will be at no cost to you.



Inside view of ENVIROMUX-SEMS-16