## **USB KVM SWITCH**

#### Control up to 32 USB computers with one USB keyboard/mouse and VGA monitor



## **Features & Applications**

Control up to 32 USB-enabled computers with one USB keyboard, USB mouse and VGA monitor with the UNIMUX<sup>TM</sup> KVM switch.

Dedicated internal microprocessors emulate keyboard and mouse presence to each attached computer 100% of the time so all computers boot error-free.


- Boot all USB computers in ONE operation.
- Supports crisp and clear 2048x1536 video resolution with no degradation.
- Fully compliant with USB standards (1.0, 1.1).
- Compatible with USB-enabled PC, SUN and MAC computers.
- USB SUN start-up keys are supported.

- SUN extra keys are emulated on USB keyboards with Windows keyboard layout.
- USB MAC start-up keys are supported.
- Supports international keyboard layouts in auto-detection mode.
- Available with RS232 control option.

## Cascade to add ports to your switch

- Cascade 4, 8 or 16-port UNIMUX switches off a single master switch to control up to 1,024 computers as if from one switch.
- Cascaded switches use computer/video ports and the remote port on the master switch.

## **Configuration and Cable Illustration**







www.networktechinc.com/srvsw-usbu.html

2

## USB KVM SWITCH

## Control up to 32 USB computers with one USB keyboard/mouse and VGA monitor

## **Specifications**

#### **Hosts**

- Female 15-pin HD and female USB Type B connectors.
- Supports SUN Blade 100, SUN Blade 1000, SUN Ray, SUN Fire<sup>TM</sup> 240, and SUN Fire<sup>TM</sup> V20z.
- Supports PCs with USB-enabled OS (Windows 98/ME/2000/ XP, Windows Server 2003, Linux) and USB ports.
- Supports PCs with USB-enabled BIOS (legacy USB support) and USB ports.
- Supports MAC G4, G5 and Xserve. Supports MAC soft (keyboard) power-on.
- Any legacy PS/2 or SUN computer can be connected by using a USB-PS2-R or USB-SUN-R.

#### **Monitor**

- Crisp and clear 2048-1536 resolution.
- Female 15-pin HD connector.
- A multiscan VGA monitor is required to display the different video outputs from different platforms.
- Bandwidth is 150 MHz.

#### **Devices**

- Female USB Type A connectors.
- Compatible with most USB keyboards and mice, including Microsoft USB Intellimouse®, Logitech Cordless Elite Duo keyboard and mouse, Gyration keyboard/mouse and Crystal Vision keyboard with touchpad.
- Keyboard and mouse are hot-pluggable.
- Supports up to eight USB devices (keyboards and mice only) using USB hubs (not included).

#### **Power**

- 110 or 220 VAC at 50 or 60 Hz via AC adapter for 2-, 4-, 16-, and 32-port models.
- 110 or 220 VAC at 50 or 60 Hz via IEC connector for 4-port with RS232 option and 8-port models.

#### **Regulatory Approvals**

- CE.
  - Available on all models except UNIMUX-USBV-2

· Two years.

## **Built-in Control Methods**

#### **Front Panel Interface**

- Touch a button and be connected to a computer, or change modes of operation.
- LEDs indicate currently selected port and mode of operation.
- Hold in any button for more than five seconds to go into Scan, Broadcast or Command Mode.
  - In **Normal Operating Mode**, the user can directly operate the selected computer with transparent presence of the NTI switch.
  - **Scan Mode** automatically and sequentially displays the video from each powered-on computer. Duration of display can be 2-255 seconds.
  - Broadcast Mode allows the user's keystrokes to be sent to all powered-on computers. (Broadcast Mode is not available for MACs.)
  - Command Mode allows the user to give instructions to the switch through his/her keyboard. Keystrokes are not passed to the computer.

#### **Keyboard**

- Scan, Broadcast or Command Modes are available from the keyboard.
- Use the keyboard to command the switch box to select ports or configure the **SCAN** delay.
- Type  $\langle Ctrl \rangle + \langle \cdot \rangle$  (or  $\langle Compose \rangle + \langle \cdot \rangle$ ) to go into Command Mode. (" " is the accent mark located on the same key as the tilde "~").
- Press <Esc> to leave Command Mode and return to Normal or Scan Mode.

#### On Screen Display (OSD)

- Select computers by name with On Screen Display (OSD). Not available on 2-port switch.
- Use keyboard or mouse to operate the switch from menus superimposed onto the monitor.
- Shows names of computers on cascaded switches up to 152 ports.
- Names can be up to 12 characters long.
- Power status of each computer is displayed.
- Help screens assist users with the OSD.
- Modify the size and position of the OSD.
- OSD is built into the switch-no need to install additional hardware or software.
- OS and software-independent.

#### **Security**

- Advanced security included.
- Each user password and name can be up to 13 characters long, and each switch can store up to 63 users.
- Administrator can enable or disable all security features and select which computers each user can access.
- Once security is enabled, a user or administrator must login in order to access any of the computers connected to the switch.





# www.networktechinc.com

## **USB KVM SWITCH**

## Control up to 32 USB computers with one USB keyboard/mouse and VGA monitor

## PS/2 to USB and SUN to USB Adapters



#### **USB-PS2-R**

- The USB-PS2-R adapter connects a legacy PS/2 computer to an NTI USB KVM switch.
- Two female USB Type A and two male 6-pin miniDIN
- One-meter male USB Type A to male USB Type B cable is included.
- Dimensions WxDxH (in): 2.4x4x1.1



#### **USB-SUN-R**

- The USB-SUN-R adapter connects a legacy SUN computer to an NTI USB KVM switch.
- Two female USB Type A and one male 8-pin miniDIN connectors.
- One-meter male USB Type A to male USB Type B cable is included.
- Dimensions WxDxH (in): 2x3.7x1.1

## RS232 Control Option

- Baud rate 300 through 9600, DIP switch selectable.
- Use DIP switches to address up to eight units, all of which can be daisy-chained and controlled by one serial port.
- Female DB9 connector.
- Add "RS" to the end of the part number to specify this option.

## **Rackmount Option**

- Optional feature. Only available on the 2-port switch.
- Add "R" to the end of the part number for a rackmount in a

## **Ordering Specifications**

This example explains the NTI part number by breaking it down into the available options. When ordering, choose the options that you require.

> Universal Serial **Bus Version**

Number Optional Rack of Ports

Mount

Control Method

**UNIMUX - USBV** 

x" = 2, 4,

**Enclosure** 

Only 8, 16, 32 available on 2-port switch

USB KVM Switch Models				
NTI Part #	# of CPUs (x)	Desktop Size WxDxH (in)	Rack Units	Rack Size WxDxH (in)
UNIMUX-USBV-2	2	5.2x4.2x1.6	NA	NA
UNIMUX-USBV-2R	2	NA	1RU	19x10x1.75
UNIMUX-USBV-40	4	13.3x5.9x1.75 (without supplied rackmount kit)	1RU	19x5.9x1.75 (with supplied rackmount kit)
UNIMUX-USBV-80	8	13.3x5.9x1.75 (without supplied rackmount kit)	1RU	19x5.9x1.75 (with supplied rackmount kit)
UNIMUX-USBV-16O	16	N/A	2RU	19x10x3.5
UNIMUX-USBV-32O	32	N/A	4RU	19x10x7

### **Cables**

- Interface cables between your computers and the switch are required for proper operation. Use USBVEXT-xx-MM and standard interface cables to connect switches to computers.
- Cables not included.





800.RGB.TECH (800.742.8324) Toll Free: US & Canada

